


138.S - Spare strap



Description:

- To be used with the nylon strap wrench.
- 138.S17: spare strap L.430 mm for 138A.17.
- 138.S30: spare strap L.760 mm for 138A.30.
- 138.S48: spare strap L.1200 mm for 138A.48.

	Weight [g]
138.S17	26.0
138.S30	74.0
138.S48	44.0